

## **CCMI Installation Procedures**

### **Fascia**

**CCMI** products have been designed to attach to the surface easily. Professional installation is recommended, but can be completed by anyone with the proper tools and instruction.

#### **Installation of Fascia-**

To install the **Fascia** you must bend an aluminum j-channel 3 inches x  $\frac{3}{4}$  inch x  $\frac{3}{4}$  inch. Nail the j-channel to the face of the fascia board covering both the soffit and the bottom of the fascia board.

Next take out the **Fascia** out of the box and hook the bottom of the **Fascia** over the nailed in j-channel. After it is locked in, make sure the top portion is flush on the top and bottom.

Nail the top of the **Fascia** to the sheathing. There is a 5/8-inch nail hem provided to nail into. Use trim nails with a nailing tool if shingles have been nailed down. This will help reduce the possible breakage of shingles from pulling them up to nail.

To finish the ends of the **Fascia** you must scribe the pattern on a piece of aluminum and cut out the excess material with shears or a utility knife. Leave your scribed piece a little long to allow for back caulking and to provide a finished look from all angles.

When two pieces need to be mitered, and joined together in a gable, you will need to butt the two pieces of **Fascia** together and snip off areas that prevent some overlap. Flash and caulk appropriately to reduce the risk of water penetration.