



Carolina Custom Moulding Inc

Installation Procedures Window & Garage Pediments

For Siding Applications

CCMI products have been designed to attach to most surfaces easily. Professional installation is recommended, but can be completed by anyone with the proper tools and instruction. CCMI pediments can be used for new construction or for remodeling. The installation instructions will be the same.

Installation of CCMI Pediments

To install **Pediments** you must first determine the appropriate size pediment you will need. Measure the distance from the outside of the J--channel or brick mold to the outside of the J-channel or brick mold on the corresponding side. That measurement will be the pediment size at the bottom of the pediment that you will order. You will have a choice of a 6" or 9" pediment.

Next, take the expanded polystyrene foam board out of the box, and secure it 1/8th-3/16th over the window or garage door opening with a latex silicone adhesive and nails.

(Do not use Liquid Nails)

Once the foam is secure you will need to nail a **J-channel** around the top and sides of the foam, which is attached to the sheathing. If the window has a J-channel built in, you will need to connect your J-channel to it, which will produce one continuous J-channel for water to escape.

Apply some silicone adhesive to the exposed side of the foam. **(Do not use Liquid nails)**

Now that the foam and J-channel are secure, you may hook the top of the pediment over the J-channel, and the bottom between the top of the window opening and the bottom of the foam.

The bottom of the pediment will slide between the window and the foam and lock in.

Notch the bottom back side of the pediment in both corners 1", to allow for the J channel to continue through the bottom portion of the window pediment.

The pediment is now secure to the sheathing, and you may continue siding the wall

